

Main Hall Wall Up-Lights - INSTRUCTIONS

There are 16 wall lights, 8 on each side of the hall

Switched on via the wall rocker switches on the wall by the door.

These wall lights may not be set as you would want them.

TO CHANGE LIGHTING SITUATION YOU CAN ONLY

USE VOICE COMMANDS. (ALEXA COMMANDS)

Alexa voice unit is a metre above the rocker switches.

If the rocker switches are on, but the lights are off, just say clearly, "Alexa, lights on".

The wall lights' intensity and colour can also be controlled by using voice commands while standing by the switches.

IF THE LIGHTS ARE NOT THE BRIGHTNESS OR COLOUR YOU WANT, THEY CAN ONLY BE CHANGED BY OTHER VOICE COMMANDS, AS BELOW:

VOICE COMMANDS – ALL 16 wall lights to the same setting

- **WHITE** - say "Alexa, lights cool white" or "Alexa, lights warm white"
- **BRIGHTNESS** – **example** - say "Alexa, lights 50". You can say any number between 0 and 100.
- **COLOUR CHANGE** – **example** - say "Alexa, lights red" (Any basic colour can be chosen)

VOICE COMMANDS – EACH wall light's colour is set independently (great for effect and parties)

Each light can be changed one by one. There are many colours available, but for impact and to keep it simple, we suggest staying with the basics.

RED – GREEN – BLUE – YELLOW - WHITE - MAUVE - etc.

Each wall light is identified by a number, 1 to 16. See example below:

- **COLOUR CHANGE** – say "Alexa, light 1 red" or "Alexa, light 2 green", etc. (This command puts the up-light on and to your chosen colour, even if the up-light is off when you start)

Alternatively, you can use one of our pre-programmed sequences: -

- **A RANDOM MIX OF COLOURS** – say "Alexa, set party lights"
- **A SEQUENCE OF RED, WHITE & BLUE** – say "Alexa, set royal lights"

TO TURN ALL WALL LIGHTS OFF - just flip the normal rocker switches